

Waterstation® Cubic 980

Einbaumaße / Installation dimensions / Dimensions d'installation / Dimensiones de la instalación

Rieber

www.riever.de

Waterstation® Cubic 980 E
right 72016620











Waterstation® Cubic 980 E
left 72016610



Waterstation® Cubic 980 U
right 72016622




Waterstation® Cubic 980 U
left 72016612





Einbau von Oben

Top mounted
Top monté
Montaje superior



Einbau Unterbau

Mounting base
Montage de base
Base de montaje





Waterstation® Cubic 980

Einbaumaße / Installation dimensions / Dimensions d'installation / Dimensiones de la instalación



Rieber

www.riever.de

Waterstation® Cubic 980 F
right 72016626




Waterstation® Cubic 980 F
left 720166116





Einbau von Oben

Top mounted
Top monté
Montaje superior



Flächenbündiger Einbau

Flush mounting
Montage encastré
Montaje empotrado



r2 = 5mm
r3 = 11mm
T2=1,5mm

